

AN/VRC-97 MSRT INSTALLATION KIT

There's a different installation kit for each vehicle in which the AN/VRC-97 mobile subscriber radio-telephone terminal (MSRT) is installed.

Each kit has the same designation, MK-2564/VRC, but each has a different NSN.

Here's what you need:

Vehicle	NSN
M1008A1	5895-01-261-2894
M1009	5895-01-261-2899
M1025	5895-01-261-2901
M113A1/A2	5895-01-261-2897
M113A3	5895-01-386-5938
M557A1/A2	5895-01-261-2898
M998 (2 door)	5895-01-368-6231
M998 (4 door)	5895-01-368-6230

You can also get a Stand-Alone Field Kit, MK-2565/VRC, with NSN 5820-01-246-6873.

Finally, get a copy of TB 11-2300-480-12. It has the installation instructions you'll need. And get a copy of TM 11-5820-1021-23&P for any needed replacement parts.

